






- power to lift



- power to lift

LOADING GROUP HC1/HD5/B3		1820-K1	1820-K2	1820-K3	1820-K4	1820-K5	1820-K6	
Туре			KX+					
TECHNICAL DATA								
Load moment	tm	17,0	16,5	16,1	15,6	15,3	15,0	
Hydraulic reach	m	6,2	8,3	10,4	12,7	14,9	17,2	
Slewing torque	kgm			1794				
Slewing angle	0			400				
Working pressure	bar			34				
Weight excl. stabilizers	kg	1420	1560	1700	1835	1955	2050	
Weight of stabilizers, standard	kg			200				
Pump performance	I/min		70-100					
Oil tank capacity, separate tank	1		90					
Power consumption	kW		40-58					
GEOMETRY								
Height above mounting surface	mm			22	50			
Width, folded	mm							
Length of crane, no extra valves	mm							
Length with 2 extra valves in internal hose reel	mm							
Dual Power Plus link arm system								
Over-bending on crane	0		Basic 20					
Over-bending on Fly-Jib	0		20					
CONTROL MODE					O .			
Radio remote control of crane				Ва	sic			
Manual operation of stabilizer functions			Basic					
Remote control box with HMF InfoCentre		Option						
Remote control box, linear control levers (L) or joysticks (J)		L/J						
Stand-up controls with bracket for radio remote control box		Option						
Top seat on column with bracket for remote control box		Option						
CONTROLS				Орі	1011			
RCL 5300 Safety System				Ra	sic			
Proportional control valve type (-d) for radio remote control		Basic Basic						
Dual control of stabilizer functions (crane)		Basic						
Electronic speed adaptation system HDL-d			Basic					
OPTIONS: HYDRAULIC EQUIPMENT		1820-K1	1820-K2	1820-K3	1820-K4	1820-K5	1820-K6	
Oil cooler		1020-1(1	1020-112	0pt		1020-113	1020-10	
Fly-Jib 350 with 3 or 4 hydr. extensions				Орі		Ontion		
,				Option Option Option				
Fly-Jib 600 with 3 or 4 hydr. extensions				Option				
Multi-coupling for extra valves in hose guides 1500 kg or 2500 kg hydraulic winch on the crane			Option					
1500 kg or 2500 kg hydraulic winch led via the Fly-Jib			Option Option					
Radio remote controlled stabilizer functions			Option					
Extra valves in hose guides				Option Option				
Extra valves in hose reels internally in the jib extensions						On#!		
Extra valves in external hose reels on Fly-Jib				Option	Option	Option		
90 I oil tank mounted on the crane		4000 164	1008-10	Opt		4000 1/5	4000 1/0	
OTHER EQUIPMENT		1820-K1	1820-K2	1820-K3	1820-K4	1820-K5	1820-K6	
Number of manual extensions			3	3	. 3	2	1	
Work light on crane			Option					
Work light on Fly-Jib			Option Option Option					
Available radio remote controlled valve section fitted on the base				Opt				
1 or 2 extra valves on Fly-Jib in hose reels					Option	Option		



180° swing-up stabilizer leg

Swing-up stabilizer leg to 180° with or without radio remote control.



Double link arm system

The HMF dual Power Plus link arm system has an excellent lifting capacity at long reach and in high positions as well as it makes it possible to lift a heavy load close to the column.



Multi-coupling

A multi-coupling makes it easy and simple to mount and dismount hydraulic accessories.



Minimum space requirements

Minimum space requirements for the large crane range give you more space on the truck body - and better economy.





The HMF radio remote control is part of a unique operation and safety system (TCC - Total Crane Control), which provides the operator with all advantages and possibilities for operating the crane functions and important safety functions on the HMF RCL Safety System. By means of the remote control box you can carry out many tasks besides operating the crane, independent of a fixed control position.




HMF's patent pending stability safety system, EVS, is continously taking into account the current load on the vehicle so that crane and truck are in perfect balance. As the system includes the load on the truck body as a part of the tare weight of the vehicle, it means that you actually obtain a considerably larger working area with a load on the truck body - thanks to EVS. This means that you obtain both an extraordinary high level of safety and larger capacity with EVS.



A well-known and usual hose routing to the end of the extensions means that 1 or 2 extra valves are fed in sturdy hose guides alongside the jib extension system. If further efficient protection of the hoses is required, 1 or 2 extra valves can be fed in internal hose reels and lie particularly well protected. In case of more than 6 hydraulic extensions or a reach of approx. 17 m, 1 or 2 extra valves will be fed in external, smooth-running and efficient hose reels.



The stabilizer legs of the crane are to ensure stability - however they still have to be sturdy, easy to handle and must not take up too much space when not in use. Therefore you can choose between fixed stabilizer legs, manual swing-up stabilizer legs to 180°with gas spring or fully hydraulic swing-up stabilizer legs to 180° . Stabilizer beams can be freely selected as hydraulically extensible or manually extensible, also in connection with the sophisticated EVS stability monitoring.



▼ Lifting capacity, no manual extensions∇ Lifting capacity with manual extensions

NSW Unit A, 9 Cunneen Street, Mulgrave NSW 2756

VIC 54 Venture Drive, West Sunshine VIC 3020

WA 71 Barberry Way, Bibra Lake WA 6163

Ph: (02) 4587 7411 E: sales.nsw@we sales.nsw@west-trans.com.au Ph: (03) 9325 1114 E: sales.vic@west-trans.com.au Ph: (08) 9494 2929 E: sales.wa@west-trans.com.au

QLD Ph: 0411 244 717 E: sales.qld@west-trans.com.au

www.west-trans.com.au



power to lift **HMF Group A/S**

Oddervej 200 · DK-8270 Højbjerg Tel.: +45 8627 0800 · Fax: +45 8627 0744 · info@hmf.dk

www.hmf.dk